

DuPont™ Neutrafoam

MULTIPURPOSE HIGH FOAMING CLEANER

DuPont™ Neutrafoam Multipurpose High Foaming Cleaner:

- Phosphate free
- A stabilized, long-lasting foam for enhanced cleaning power
- Hard water tolerant
- Neutral pH
- For manual cleaning, truck wash, all transportation vehicles, and food processing facilities
- For use in hatcheries, animal confinement facilities where neutral pH is desired
- Excellent end-use compatibility with DuPont disinfectants
- Formulated with Biodegradable Detergents

COMPONENTS

Components	CAS No.
Water.....	7732-18-5
Surfactants	—

FOR INDUSTRIAL AND COMMERCIAL USE ONLY

KEEP OUT OF REACH OF CHILDREN

CAUTION / AVISO

NET CONTENTS: 1 Gallon (3.78L)

FIRST AID

IF INHALED: Remove to fresh air. If not breathing, give artificial respiration. If breathing is difficult, give oxygen. Call a physician.

IF ON SKIN OR CLOTHING: Flush skin with water after contact. Wash contaminated clothing before reuse.

IF IN EYES: In case of contact, immediately flush eyes with plenty of water for at least 15 minutes. Call a physician.

IF SWALLOWED: If swallowed, do not induce vomiting. Immediately give 2 glasses of water. Never give anything by mouth to an unconscious person. Call a physician.

Have the product container or label with you when calling a Poison Control Center or doctor or going for treatment.

For 24-hour emergency information on this product, call 1-800-441-3637 (US & Canada) or 1-302-774-1139(all other areas).

PRECAUTIONARY STATEMENTS

CAUTION: May cause eye, nose and throat irritation. Avoid contact with eyes, skin and clothing. Avoid breathing vapor or mist. Wear safety glasses. Where splash potential exists, wear chemical splash goggles. Where there is potential for skin contact have available and wear as appropriate impervious gloves, apron, pants and jacket. Wear NIOSH approved respiratory protection, as appropriate. Use and store only with adequate ventilation. Wash thoroughly after handling.

STORAGE AND DISPOSAL

Store in original container, in areas inaccessible to children. Keep container tightly closed. Do not store on side. Avoid creasing or impacting of side walls. Do not reuse empty container. Discard in trash or recycle.



The miracles of science™



RECOMMENDED AREAS OF USE

DuPont™ Neutrafoam is ideal for use in truck wash, all transportation vehicles, manual cleaning, food processing, hatchery and animal confinement facilities where neutral pH is desired.

DIRECTIONS FOR USE

FOAMING: Manually prepare a stock solution of between (0.5-3.0 ounces per gallon) (4-24 ml/liter) of DuPont™ Neutrafoam or calibrate the dosing equipment to achieve the required dilution. The amount may vary depending on the soil load and how difficult the surface is to clean. Using a foaming lance apply DuPont™ Neutrafoam to all surfaces at an application rate of 0.8 oz/ft² (250 ml/m²). Allow a minimum contact time of 5-10 minutes before thoroughly rinsing all surfaces with clean water at high pressure. After thorough pre-cleaning, follow-up with an application of an appropriate disinfecting solution.

LOW OR HIGH PRESSURE WASHING: Manually prepare a stock solution of between (0.5-2.0 ounces per gallon) (4-16 ml/liter) of DuPont™ Neutrafoam or calibrate the dosing equipment to achieve the required dilution. The amount may vary depending on the soil load and how difficult the surface is to clean. Spray the solution onto all surfaces using a low pressure lance and at an application rate of 1.6 oz/ft² (500 ml/m²). Allow a minimum contact time of 5-10 minutes before thoroughly rinsing all surfaces with clean water at high pressure. After thorough pre-cleaning, follow-up with an application of an appropriate disinfecting solution.

TRUCK WASH, TRANSPORTATION VEHICLES: Use DuPont™ Neutrafoam at a use solution (0.5-3.0 ounces per gallon of water) (4-24 ml/liter), depending on water quality and soil load for cleaning. Apply by spraying or foaming to surfaces and, if possible, let stand for 5-10 minutes before thoroughly rinsing all surfaces with clean water. After thorough cleaning and rinsing, let surfaces dry as much as possible and then follow-up with an appropriate DuPont disinfecting solution. Consult a DuPont Technical Representative for recommendations.

FOOD & EGG PROCESSING EQUIPMENT, UTENSILS AND OTHER FOOD CONTACT SURFACES: Follow foam cleaning instructions. Thoroughly rinse cleaned surfaces with potable water before they are reused. Where recommended or permitted, apply a sanitizer solution to food contact surfaces before reuse.

BEFORE USING, READ THE MATERIAL SAFETY DATA SHEET (MSDS) FOR THIS PRODUCT.

MANUFACTURED FOR:

E. I. du Pont de Nemours and Company
DuPont Animal Health Solutions
PO Box 80023, Wilmington, DE 19880-0023 USA

Questions? Call 1-800-441-7515
Outside the US, contact: 1-302-774-1000

DuPont Animal Health Solutions

1007 Market Street
Wilmington, DE 19898

Phone: 1-800-441-7515 or 1-302-774-1000

Fax: 1-302-892-7656

Email: biosecurity@gbr.dupont.com

www.ahs.dupont.com



The miracles of science™